


# Cosmo Table Light


---

## Instruction Manual




---


Plain  
FT448




Stepped  
FT449



Dimpled  
FT450



Prismatic  
FT451



---

Established in 1990, Original BTC manufactures relaxed, familiar lighting for traditional and contemporary homes.  
All products are hand-assembled in Oxford from high quality components, produced in the UK.




---

# Cosmo Table Light

| 230V ac 50Hz | IP20 |

FT448	Plain
FT449	Stepped
FT450	Dimpled
FT451	Prismatic

The Cosmo collection includes pendant and table lights with a shortened, semisphere shade. Available in ribbed prismatic glass or bone china with either a plain, dimpled or stepped finish, the textural shades take on a new dimension when lit, creating beautiful shadows.

LAMP GUIDANCE Cosmo Table Light				
BASE	SHAPE	TYPE*	WATTAGE**	
			FT448/FT449/FT450	FT451
	 	INCANDESCENT ✓	40W MAX	60W MAX
E14	CANDLE BALL	CFL ✓	11W	13W
		ECO-HALOGEN ✗	n/a	n/a
		LED ✓	7W	9W

\* Warm white (2700k) low energy lamps recommended.  
 \*\* Wattage value provided as a guide to suitable lamps. Lower wattage than stated may be used.

## Safety Instructions



These instructions are provided for your safety in order to prevent the risk of Fire, Electric shock or Injury. Please retain for future reference. When fitting is in operation, some parts will become hot; take care when using/handling.

- Ensure the lamp type and max wattage is followed- do not exceed. Take care not to overtighten lamp.
- Do not touch the lamp (bulb) or lamp holder while in operation, as both become very hot.
- Turn off and unplug fitting, leaving lamp to cool before changing lamp. Dispose of old lamps carefully.
- Adjust light fitting only when power to the fitting is off and has been left to cool.
- Never leave a fitting without a lamp in position.
- Keep light fitting away from combustible materials such as soft furnishings.
- Ensure children do not play with the light fitting.
- Ensure the light is positioned on a solid, level and non-slip surface and make sure the position of the cable does not pose a trip hazard.
- If the electrical flex or electrical components become damaged at any point, the fitting must be unplugged from the power supply immediately and not operated until the damaged parts are fixed/replaced.
- For use in a dry, indoor environment only. Ensure the fitting does not come into contact with any liquids.

## Cleaning and Maintenance

Metal finishes should only be cleaned with a soft, dry cloth. Do not use polishes or abrasives. Bone china can be cleaned by hand, using a soft damp cloth with a diluted mild detergent (nonabrasive) if necessary. Switch off power to the fitting before cleaning.

## Assembly

Cosmo Table- Plain/Stepped/Dimpled	Cosmo Table- Prismatic
	
A Cap B Shade C Nylon Washer (Bone China version)	D Bracket E Table stem/Base F Metal Washer* (Prismatic version)

### Cosmo Table- Plain/Stepped/Dimpled

- Place the nylon washer (C) on top of the bracket (D), then place the shade on to the washer/bracket, so that the top hole lines up centrally with the washer and bracket.
- Hold the shade in position, before placing the thread of the cap (A) through the hole of the shade and washer, before screwing firmly into top of bracket to secure the shade in place. Do not overtighten cap.

### Cosmo Table- Prismatic

- Place one metal washer (F) on top of the bracket (D), then place the shade on to the washer/bracket, so that top hole lines up centrally with both the washer and bracket.
- Hold the shade in position, then place the second metal washer on top of the shade before placing the thread of the cap (A) through the hole of the shade and washer, before screwing firmly into top of bracket to secure the shade in place. Do not overtighten cap.