



#### Datos Técnicos

Luminaria para uso interior  
Factor de Potencia: 1  
Lámpara a utilizar:

#### Scotch Club 17

G9 ECO 48W   
G9 LED 2,2W 

#### Scotch Club 26

E27 HSGSA/C/UB 57W   
E27 LED Standard 8W   
E27 FBA 15W 

Se recomienda que la instalación sea realizada por un profesional.

**Aviso:** Si el cable flexible o cordón de esta luminaria está dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.



#### Instrucciones para la limpieza

Se recomienda limpiar con aire. Se puede utilizar un secador de pelo. También es posible realizar la limpieza con un cepillo limpio.

#### Technical Data

Light fitting for indoor use only  
Power Factor: 1  
Bulb to be used:

#### Scotch Club 17

G9 ECO 48W   
G9 LED 2,2W 

#### Scotch Club 26

E27 HSGSA/C/UB 57W   
E27 LED Standard 8W   
E27 FBA 15W 

*A professional electrician should be responsible of the light installation.*

**Warning:** If the wire or flexible cord is damaged, it has to be changed exclusively by the manufacturer, his technical service or a qualified personnel in order to avoid any risk.

#### Cleaning Instructions

*It is recommended to use a hair dryer or a clean brush to remove dust from the surface.*



Aislamiento básico más aislamiento reforzado.  
Toma de tierra: excluida.

*Basic insulation plus second insulation or both replaced by reinforced insulation.  
Earthing: excluded.*

Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.




*This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.*

230 V - 50 Hz

# SCOTCH CLUB 17 & 26


Instrucciones de Montaje / Assembly Instructions



marset



marset



---

**Atención!**

Desconectar la conexión a red antes de ser manipulada y realizar el cambio de bombilla sólo cuando esta se haya enfriado.

**Warning!**

Disconnect power supply before installation and change the bulb only when cold.

---

1. Fijar el soporte (A) mediante los tornillos y tacos (B) que se suministran, pasando los cables de red por el orificio.
2. Introducir el cable (C) por el interior de la pantalla cerámica (D) y a continuación por el florón (E). Fijar el cable atornillando el prensacables (F) utilizando la llave allen suministrada.
3. Realizar las conexiones eléctricas en la caja de empalmes (G).
4. Subir el florón e inmovilizarlo atornillando el prensacables (H).
5. Colocar la bombilla recomendada.

1. Fix the support (A) using the plugs and screws (B) provided, having passed the mains cable through the round hole.
2. Introduce wire (C) up through the inside of the ceramic shade (D) and then up through the ceiling rose (E). Clamp the cable by tightening the slack adjuster (F) with the Allen Key supplied.
3. Connect all the wiring to terminal strip (G).
4. Raise the ceiling rose (E) and immobilise it by fully tightening slack adjuster (H).
5. Insert an approved bulb.